RHINO Mobility

2D Barcode Scanner

User's Manual

RM1770

V1.0.1

intro

This user's manual is designed for 2D barcode scanner. For detailed usage information, please download the complete user's manual from our website or from our authorized distributors.

Scanning the corresponding setting code, you can change the bar code scanner related function Settings.

System settings

Factory default settings

Factory default settings

Note: Factory default settings are marked with an asterisk "*" in this manual.

Interface

USB-KBW(*)

USB-COM

RS-232

Barcode setting

Activate scanning of all barcode types

Turn on default reading type (*)

Video Reverse OFF(*)

Video Reverse ON

Reading mode

Manual mode(*)

Continuous mode

Automatic mode

Sensitivity

Low(*)

Middle

Sound

On(*)

Off

illumination

Reading Normal(*)

Off

On

Aiming

Reading Normal(*)

Off

On

USB-KBW Setting

Virtual keyboard

standard keyboard(*)

Virtual keyboard

Ctrl

Alt

Control character output is off(*)

Data output encoding format

GBK(*)

UTF8

Original data output

UNICODE

CapsLock Status Settings

CapsLock-Off

CapsLock-On

Web address code recognition

Enable(*)

Disable

Add terminal key stroke

Deactivate terminal addition

Add terminal CR(*)

Add terminal TAB

Add terminal CR+LF

Keyboard layout

USA(*)

Czech

French

Germany

Hungary

Italy

Japan

Spain

Turkey Q

Mexico (Latin America)

RS-232 Setting

Baud rate

1200bps

4800bps

9600bps(*)

14400bps

19200bps

38400bps

57600bps

115200bps